

| ASTM  | ASTM  | DIN      | DIN     | DIN  |  |
|-------|-------|----------|---------|------|--|
| D141E |       | TEN ISOF | 1 ISO F |      |  |
| 01415 | 02240 | 868      | 48-2    | 48-4 |  |

### Hardness testing solution for rubber performed in extreme temperatures

Performing hardness tests in a temperature simulated environment.



The Bareiss digiChamber is a perfect solution to analyse how rubber hardness changes. In collaboration with the renowned temperature solution provider "Weiss Technik", the digiChamber uses temperature simulations with the best accuracy. Maximize your testing capability and capacity with digiChamber-R, using our computer-controlled, serial digiChamber to check the hardness of polymers, with a temperature range between-70°C and +180°C. The associated hardness tester digi test II is mounted externally, to avoid temperature-related measurement errors. Only the connected indenter is installed inside the chamber.

Conveniently equipped with an inspection window on the front door, the rotation table, with user-specific templates, positions the test specimens one after the other under the measuring device, for the automatic measurement. Alternatively, you can align molded parts individually and manually, using the side chamber opening. With the "digiCenter" software, you can control the temperature and humidity, measuring rhythm and the number of measuring points, as well as manage the determined values in a database. For the output of temperature-related hardness values, the program offers both graphics and value tables.

#### **TEST METHODS**

Shore A IRHD N



#### DIN EN ISO DIN ISO 48-2 DIN ISO 48-4 ASTM ASTM ΕN D1415 D2240 868 **D** Hardness scales **MAIN FEATURES** Including monitor and interchangeable software digiCenter to conbetween Shore A trol chamber and hardness A Web based measuring and and IRHD N. testing device. control system with I/O unit Integrated IPC for and **WEB**Season software in complete control. a 7" touch panel. **C** Electronic console with digital I/O for controlling the hardness system. **B** Large test volume of 200 liters with polished stainless E Air-cooled steel walls for test refrigeration unit ٠ load of up to 125 kg. with continously variable power adjustment by SIMPAC and chloride-free refrigeration cycle.



Rubber becomes hardened in an extreme cold environment. Simulate an environment as cold as -40° C with digiChamber.



Crank up the digichamber to +180°C (recommended at +150°C) to anaylse how rubber changes its hardness in extreme heat.



The automatic rotating tray can carry up to 25 pcs of samples. Users can design a test sequence by selecting number of measurements per sample and the desired temperature.



#### EN

ASTM ASTM DIN DIN DIN DIN DIN DIN DIN ISO ASTA

digiCenter is a modularized software that is aimed to provide a common platform with integration of the control of the temperature chamber as well as the hardness testing device. By combining these two worlds, digiCenter proved to be a very valuable tool to control and analyze temperature depending hardness testing.

Whether it is a standard test for one single measurement or a series of tests that requires a complex test sequence editing, BareissOne is designed to offer all levels of user's demands.





| -     |          |    | and here |                    |                 |
|-------|----------|----|----------|--------------------|-----------------|
| -     |          |    |          | 1.000 E.000        | -               |
|       |          | -  | 1.00     | a magine           | A. Barrison II. |
|       | -        |    | -        | -                  | 122             |
| -     | signe.   | ** | -        |                    | 1000            |
| -     | -        | *1 | 1.10     | -                  | 100.00          |
|       | ingene . | -  | **       |                    | 10100           |
| -     | -        | *1 | - 214    | Accession in the O | 1000            |
|       | -        |    |          |                    | 1000            |
| and a | Anna .   |    | **       |                    | -               |

#### User management

Allows the administrator to assign permissions to each individual user. Add, amend and delete roles quickly and implement them across platforms and applications.



#### **Graphic tutorials**

With graphic tutorials integrated in digiCenter, users can quickly learn how to set up and use digiChamber with much less effort.



#### **Report and Analysis**

Generate your custom test report with Microsoft Word-like user interfaces. Export the report in either CSV or Excel format.



### EN

#### 

#### SPECIFICATIONS

#### Shore A hardness system

| Standard:              | DIN ISO 48-4, ASTM D 2240 |
|------------------------|---------------------------|
| Spring force:          | 8050 mN                   |
| Force on presser foot: | 1 kg                      |
| Presser foot size:     | Ø 18 mm                   |
| Indenter:              | 35°                       |
| Penetration:           | 2.5 mm                    |

#### IRHD N hardness system (Optional)

| Standard:              | DIN ISO 48-2, ASTM D 1415 |
|------------------------|---------------------------|
| Initial load:          | 0.3 N                     |
| Primary load:          | 5.7 N                     |
| Force on presser foot: | 8.3 N                     |
| Presser foot size:     | Ø 20 mm                   |
| Indenter:              | Ø 2.5 mm                  |
| Penetration:           | 1.8 mm                    |

#### **Electrical and interfaces**

| Voltage:          | 100-240 VAC, 50/60 Hz; 12 A |
|-------------------|-----------------------------|
| Power:            | approx. 1.8 kW              |
| Protection Class: | IP 54                       |
| USB:              | 3.0 (1 port)                |
| Ethernet:         | 100/10 megabit              |

#### Compressed air

| Pressure:      | 4 – 12 bar |
|----------------|------------|
| Consumption:   | max. 6m³∕h |
| Coupling type: | DN 7.2     |

#### Specimen

| Туре:     | Plate shape samples                  |
|-----------|--------------------------------------|
| Standard: | Ø 38 mm / 50 mm<br>others on request |

### Temperature chamber

| Temperature range:    | -70°C to 180°C      |
|-----------------------|---------------------|
| Recomm. max. temp.:   | 150°C               |
| Temp. rate of change: | ±0.2 K to ±0.5 K    |
| Temp. homogeneity:    | ±0.5 K to ±1.5 K    |
| Test volume:          | approx. 200 liters  |
| Heat compensation:    | 800 W               |
| Noise level:          | 56 dB (A)           |
| Refrigerant:          | Chloride-free R449A |





### ASTM ASTM DIN EN ISO B68 48-2 48-4

#### ACCESSORIES

FN



#### IRHD Normal measuring device As an optional measuring

device to the digiChamber.



#### **Standard block** Choices of 1, 3 and 6 pcs set premium quality standard blocks with DAKKS certificates.



#### DAKKS calibration certificate Bareiss offers the most

prestigious certificate for your quality assurance.



#### digiCenter software

A modular software that provides ease of use for all levels of user demands. It includes many key features that are essential for effective testing process and accurate results.



#### BareissCare Service The BareissCare service package provides extended calibration and maintenance services.

#### REFERENCE

Bareiss offers a comprehensive range of consumables and accessories for you to conduct your tests. All these products are proven to be premium quality.



#### Bareiss Prüfgerätebau GmbH

DAkkS-Kalibrierlaboratorium Breiteweg 1 89610 Oberdischingen, Germany Tel +49 (0) 7305 / 96 42-0 Fax +49 (0) 7305 / 96 42-22 sales@bareiss.de







www.bareiss.tv



(III)

MADE IN GERMANY SINCE 1954.

The accreditation is valid for the scope listed in certificate D-K-15206-01-00 (mechanical measurands in the range of hardness).